

PuduBot 2 — Quick Start Guide

1. **Power on/off:** Long-press for 3s at the Starting point (note orientation).




2. **Charging:** Please charge the robot immediately if the power is lower than 10%.




3. **Food Delivery:** Choose table number and click Start to deliver (with dining scene voice).




4. **Delivery:** Choose destination and click start to deliver (with general scene voice).




5. **Cruise:** To select the route to cruise.




6. **Direct delivery:** One arrival point and one-way delivery.




7. **Birthday:** To deliver cakes and gifts with the Birthday Song.




8. **Collecting:** To collect the things to be cleaned and delivers them to the collecting point.



9. **Pause:** Click screen to pause.



10. **Setting:** To change language, maps, speed, volume, etc.



11. **Emergency stop:** Press the red button on the top to stop the robot immediately and restore by rotation and ejection.

12. Do not deliver liquid dishes, such as soups and hot pot, which may spill liquids and cause other accidents.

13. Do not block the robot while it is moving, so as to avoid safety accidents.

14. Do not obscure the radar, RGBD or VSLAM camera with any foreign objects.

15. Please designate a person responsible for charging the robot strictly regulating the charging operation.

16. Please keep the robot dry and at room temperature for storage and charging. Do Not charge at $>40^{\circ}\text{C}$ and avoid water.