


KettyBot - Quick Start Guide

Power on: long-press the power button for 3s.




Charging: connect to the charger immediately when the power is lower than 20%. Or replace the quick-release battery (if any).



Delivery: Click on the corresponding table number on the delivery mode interface and click start.





Cruise: Select the cruise route on the cruise mode interface and click start.





Customer attraction: Select the customer attraction mode and click to go, the robot will go to the location for customer attraction to solicit customers by itself.

Escorting: Select the table number in the escorting mode interface, and the customer can follow the robot to the table.



Dish-Return: In the dish-return mode, select the table number and click start, and we can set the dwell time and return interval in the settings

Self-charging: Click "charging", the robot automatically returns to the charging pile for charging (requires a charging pile)



Note

1. Press the **emergency button** on the top of the robot to make it stop immediately. Then it cannot run and the button needs to be **rotated to make it move**;
2. **Forbid** to transport **liquid dishes**, such as soup, hotpot, etc.; it is easy to cause liquid spillage and other accidents;
3. The robot has an automatic obstacle avoidance function, but it is strictly **forbidden** to block the robot suddenly during its running. Otherwise, it may cause an accident;
4. The lidar, RGBD and Marker camera are strictly **prohibited** from being blocked by any objects;
5. Please designate a person to charge the robot, **don't** charge it **unattended**;
6. Please keep the robot and its charging port in a dry storage location and at room temperature. **Forbidden** to place the robot and charger in a high-temperature area for charging (>40°C) and **let water in**;